Duratec® Polyester Hi-Gloss Topcoat



A high-build, easy-sand coating designed as a top-coat for cured polyester, polyurethane and lacquer clear or color coats.

Usage

To topcoat wood and MDF substrates, including architectural woodwork, automotive dashboards, kitchen cabinets, marine and aircraft interiors and musical instruments.

Features

You'll get a superior finish, add quality and save time and labor with Duratec Polyester Clear Hi-Gloss Topcoat.

Here's why you should choose Duratec Polyester Clear Hi-Gloss Topcoat—

Easy to apply

Sprayable and quick building, to 10-15 mils, 250-375 microns, thickness.

High gloss

Sands easily and polishes to a non-wax, tackfree high gloss finish.

Resists fisheyes

Unique additives reduce the risk of fisheyes and pinholes during the spray application.


Superior finish

You'll get a glossy, hard, chemical resistant finish.

Easily topcoated

Can be topcoated with lacquers, enamels, polyurethanes, varnishes, etc. to achieve highgloss or low-luster, handrubbed finishes.

Duratec Polyester Hi-Gloss Topcoat 904-046 Clear





Hawkeye Industries

P. O. Box 415, Bloomington, CA 92316 (USA) 800-977-0060 • (Outside USA) 909-546-1160 • Fax 909-546-1161 Email: productinfo@duratec1.com • www.duratec1.com



Product No. 904-046 Duratec® Polyester Hi-Gloss Topcoat

Data Sheet Continued

Page: 2

Product Properties

All time calculations are based on temperatures of 77°F, 25°C

Viscosity

As measured on a Brookfield Viscometer

Model RVF, Spindle #2 at 20 rpm390-450 cps

Thixotropic Index 3

Gel Time

Sample based on a 100-g mass

Coverage per Gallon

 10 mil thickness
 110-115 ft²

 250 micron thickness
 10.2-10.7 m²

Use instructions:

The use of Duratec 823A Polyester Sealer or Duratec 5604-001 Polyurethane Sealer (for oily woods or over an alcohol stain) is recommended.

- 1. Thoroughly mix the Duratec Clear Polyester Topcoat.
- 2. Measure out an amount that can be sprayed in 15 minutes...usually about a quart with a HVLP spray gun.
- 3. Assure an appropriate spray gun is available and clean. Dry compressed air is recommended for air-assisted spray guns.
 - A) 1.4 to 1.8 mm tip is ideal. About 34-40 pounds of break-up air is usually required. Use the lowest pressures possible to minimize
- orange peel.
- 4. Catalyze with 2% MEKP Catalyst like Norox 925. About 20 CC/quart is required. Stir thoroughly.
- 5. Start with a light pass over the wood or MDF. Wait two minutes, then make a build coat of 4-6 mils. Wait two minutes. Continue to make build passes, with two minute waits, until about 20 mils of Duratec is on the surface.
- Allow to cure at room temperature for at least one hour. At that time, cure can be accelerated by putting the part in a warm room at up to 120° F.
- 7. Once the surface is fully cured, sand to removed any texture or orange peel. Use as fine a grit of paper as is reasonable.
- It may be necessary to make additional build coats to eliminate all surface profile and grain texture. Allow at least eight hours after sanding before re-coating.
- 8. Continue sanding with progressively finer grits up to 1000 grit paper. Assure that at least 8 hours passes between the beginning of sanding to the beginning of polishing.
- 9. Compound and polish to a high gloss. We recommend Aqua Buff 1000W or 1000F, followed by Aqua Buff 2000

Revised 06-23-15



Hawkeye Industries

P. O. Box 415, Bloomington, CA 92316 (USA) 800-977-0060 • (Outside USA) 909-546-1160 • Fax 909-546-1161 Email: productinfo@duratec1.com • www.duratec1.com

Limited/ warranty statement: Our products are intended for sale to industrial and commercial customers. We request that customers inspect and test our products before use and satisfy themselves as to contents and suitability. Nothing herein shall constitute a warranty, expressed or implied, including any warranty of merchantability or fitness, nor is protection from any law or patent to be inferred. All patent rights are reserved. The exclusive remedy for all proven claims is replacement of our materials and in no event shall we be liable for special, incidental or consequential damages.